
The Gauges Tab

The Gauges Tab:

Gauges are associated with a specific piece of equipment and are displayed under the Gauges tab in the Equipment Details screen. A single piece of equipment can have up to fifty gauges defined for it. Once gauges have been configured, they can be added to any schedules associated with the equipment. This will create a Gauges section on all future work orders that are generated, allowing users to capture readings from the field. Users can also manually add or edit gauge readings in the Gauges tab.

Add, Edit or Delete a Gauge

 Users can delete a gauge by selecting a gauge, then clicking Delete. In the confirmation window that opens, click OK.



 Users can edit a gauge by selecting a gauge and clicking Edit. This will open an Edit Gauge window. Users can edit the gauge by following steps 2 and 3 below for adding a gauge.



To add a gauge:


1. Click Add Gauge. This will open an Add Gauge window.



- 2. In the window that opens, enter the following information:
 - Gauge Name
 - Measurement Type: e.g. Pressure, Flow, Temperature, etc.
 - **Unit**: A variety of appropriate units of measurement are provided based on the measurement type selected.
 - Gauge Type: Instantaneous or Cumulative can be selected.
 - Minimum Value and Maximum Value: These optional fields allow users to select a

maximum and minimum acceptable value.

- Frequency: How often gauge readings should be taken.
- Last Calibrated: This optional field allows users to indicate when the gauge was last calibrated.



3. Click Save once finished.

Graphing Gauge Readings

Any gauge that has had readings entered for it can be viewed as a graph:

1. Select the Gauge to be viewed as a graph.




- 2. At the bottom of the Gauges tab interface, select the Graph sub-tab if it is not already selected. The graph will be displayed to the right.
 - Hover your mouse over the graph to view detailed information concerning the plot lines on the graph.
 - The Show Readings drop-down list allows users to select the number of recent readings to display.
 - The **Show/Hide Marker** button () can be used to show or hide the graph's plot points.
 - The **Show/Hide Label** button () can be used to show or hide the numbers displayed on the graph line.






Adding and Editing Gauge Readings


Selecting the Readings tab (to the right of the Graph tab at the bottom of the screen) displays a list of all gauge readings taken for the gauge that have been selected on the left side of the interface. If a work order is associated with the collection of the reading, users can click on the work order number to view the work order's details.



 Users can add a reading by clicking Add Reading. In the Add Reading window that opens, enter a reading value, the date the reading was recorded, then click Save.



To edit a reading, select a reading from the list and click Edit. In the Edit Reading window that
opens, users can update the reading value and/or the date the reading was recorded. Click
Save to update the reading.



 To delete a reading, select a reading from the list and click **Delete**. In the confirmation window that opens, click **Yes** to delete the reading.

